

Parts:

1 - Light Bracket

12-inch Roller Fairlead LED Light Bar Mounting Bracket Any Standard Winch Roller Fairlead

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit.

REQUIRED TOOLS:

17mm Socket/Wrench

19mm Socket/Wrench

INSTALLATION INSTRUCTIONS

STEP 1: Disconnect positive battery lead before installation.

STEP 2: Remove two mounting bolts from Roller Fairlead. (Save factory hardware)

STEP 3: Place light bracket in position behind Roller Fairlead.

STEP 4: Reinstall factory hardware and tighten.

STEP 5: Install light bar in bracket using kit hardware.

STEP 6: Wire power to light bar per instructions supplied with kit.

STEP 7: Reconnect positive battery lead.

POST-INSTALLATION

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.